


## READ INSTRUCTIONS BEFORE INSTALLING

# THE Lock Locker™

INSTALLATION INSTRUCTIONS


The Lock Locker™ is a device designed to increase the security of persons while they are within their residence. Proper installation of The Lock Locker™ is easily performed (usually without tools). However, it is important to follow the instructions below carefully.



### Locate Contents Included in The Lock Locker™ package:

- 1) The two "Round" pieces (one has an oval opening and the other has a rectangular opening in the center. Only one will be used. Rectangular shape is most common.)
- 2) The "Flat" piece (the handle).
- 3) The "Accessory" piece (may not be required for installation. Only to be used if deadbolt and door knob are separated by a distance of more than 9").
- 4) The mounting device (screw) for the optional "Accessory" piece.


The Lock Locker™ typically installs on a door that has a deadbolt and a separate doorknob. See the figures:



Typically, a door has the deadbolt located directly above the doorknob. Most deadbolt knobs and doorknobs are located within 6" (center-to-center) of each other; but they may be as close together as 3" or as far apart as 9" in order to properly assemble The Lock Locker™ without installing the "Accessory" piece.

- If this is not the case (deadbolt is out of range of door knob, or there is NO doorknob), follow the instructions for "Installing the Accessory Piece" when installing the unit. Then proceed with the installation instructions.

## Install The Lock Locker™



- 1) From inside the residence, close the door to be fitted with The Lock Locker™.
- 2) Turn the deadbolt's knob to the "locked" position.
  - a. Note that there is probably a small amount of "play" in the knob's "locked" position.
- 3) Place the "Flat" piece over the doorknob (NOT the deadbolt's knob) by placing the round opening in the "Flat" piece over the doorknob.
  - a. Slide the "Flat" piece up to the deadbolt.
  - b. Fit the "Flat" piece's round opening over the deadbolt's knob.
  - c. If the round opening in the "Flat" piece easily reaches the deadbolt, and is able to fit over the deadbolt's knob while being retained by the doorknob, then proceed to the next step. If not, proceed to the section below titled: "Installing the "Accessory" Piece".
- 4) Select the proper "Round" piece for the correct shape of your specific deadbolt's knob (either the oval or the rectangular opening). NOTE: Rectangular shape is most common.
- 5) While holding the "Flat" piece's round opening over the deadbolt's knob (in its locked position) with one hand, place the "Round" piece depicted above (oval or rectangular) over the deadbolt's knob.
  - a. Select a mating position that easily allows the two pieces to snap together.
    - i. The mating position should be as close as possible to the locked position of the deadbolt's knob, the two pieces must NOT be forced together.
    - ii. If there is pressure on the deadbolt's knob after fitting the two pieces, temporarily remove the "Round" piece from the "Flat" piece and select one, or two, positions in the direction of the "play" (described in step 2a above).
      - The round piece opening, "Round or Oval" MUST fit over deadbolt knob easily and without any force whatsoever.
    - iii. Take note the steel ring on the round piece is to be inserted such that the steel ring is closest to you (farthest away from surface of the door and the small lip is to slip behind the deadbolt knob.
- 6) When the two pieces are mated properly, installation is complete.
- 7) When not in use, the assembled Lock Locker™ hangs conveniently from doorknob or "Accessory" piece.
- 8) Verify installation by following the guide below.

## IMPORTANT:

- The Lock Locker™ is meant to fit loosely over the deadbolt for easy removal. The loose fit is NOT a mistake and does NOT alter its effectiveness.
- The MAGNETS are NOT intended to keep The Lock Locker™ on the deadbolt, but rather to keep The Round Piece and the Flat piece together. The small lip that slips behind the deadbolt knob is all that is needed. Please do not modify/add things such as: additional magnets, string, rubber bands, Velcro, etc.

## Test and verify proper installation and operation of The Lock Locker™:

### Test One:

Perform to verify The Lock Locker™ can be put on and removed from the deadbolt lock with ease and without force.

- 1) Start with The Lock Locker™ fully assembled but, NOT installed over the deadbolt's knob.
- 2) From the inside of the residence, close the door and lock the deadbolt.
- 3) Place the round portion of the assembled Lock Locker™ over the deadbolt's knob.
  - a. Verify it fits without being forced (this is The Lock Lockers™ normal "locked" position).
- 4) Pull The Lock Locker™ away from the deadbolt's knob.
  - a. Verify that it pulls away easily.
- 5) Unlock and open the door.


### Test Two:

Perform to verify The Lock Locker™ has been installed correctly and that it will prevent the door from being unlocked by your own personal key.

- 1) While the door is open, put the deadbolt into its locked position.
- 2) Place the round portion of the assembled Lock Locker™ over the deadbolt's knob.
- 3) From the outside of the door, try to unlock the door with its legitimate key.
  - a) Verify that the key does NOT unlock the door and that The Lock Locker™ remains in place.
- 4) Once the above steps are completed, remove The Lock Locker™ and let it dangle again to its "resting" or "ready" position.
- 5) Installation is now complete.

### Installing the "Accessory" Piece (If required):

If the center-to-center distance between the doorknob and the deadbolt's knob is too small or too large; or, if there is NO doorknob, then the "Accessory" piece must be installed onto the door. See the figures:



Distance greater than 9"    Distance less than 3"    No Doorknob

- 1) Locate the position for the "Accessory" piece about 6" below the deadbolt's knob. ("Accessory" piece can be mounted above deadbolt if necessary)
- 2) When mounting the "Accessory" piece to the door, be sure that the piece is mounted with its widest dimension horizontal.



- a. If the door is wooden, place a wood screw (included) through the "Accessory" piece's center mounting hole and screw the piece to the door.


- i. Double stick tape is to hold "Accessory" piece in place, but not as a substitute for the provided screw.
- b. If the door is metal, the "Accessory" piece may be screwed, or fitted to the door with adhesive hook-and-latch strips (Velcro™, etc. – not included).

### Normal daily use of The Lock Locker™:

- 1) Do NOT emplace The Lock Locker™ on **every** door and then exit your residence through your car's garage door. If electrical power were to be off when you return, the garage door will not open, and NO one will be able to enter the residence until power returns.
- 2) Demonstrate the emplacement and removal of The Lock Locker™ to **all** persons who reside in the location where The Lock Locker™ is to be used. Young and old alike need to practice the procedures until they are comfortable with the process.
  - a. To emplace:
    - i. Lock the door.
    - ii. Lift the unit up and place over the deadbolt's knob.
  - b. To remove:
    - i. Pull the unit straight away from the door (off the deadbolt's knob).
    - ii. Let the unit dangle until the next use.
    - iii. Unlock the door if desired.
  - c. If The Lock Locker™ has been completely removed from the door it is important that it be re-assembled properly (see steps 1-6 on page 1). With the "lip" of the round piece closest to the surface of the door AND **behind** the deadbolt knob and the steel ring is closest to you (farthest **away** from surface of the door.)
  - d. Occasionally verify that The Lock Locker™ has been installed correctly.

### NOTES:

- Once properly assembled, The Lock Locker™ can remain in the "resting" or "ready" position on the doorknob.



- If desired, The Lock Locker™ can be easily unassembled, removed, and then reassembled onto another door.

If The Lock Locker™ fits tightly, does not keep deadbolt knob from turning or is difficult to remove in any way DO NOT USE. **PLEASE contact us if you are in ANY doubt that installation is incorrect, for assistance or warranty information.**

Call- (855) 777-2948

Email- [customercare@thelocklocker.com](mailto:customercare@thelocklocker.com)

Instructional Videos available at [www.thelocklocker.com](http://www.thelocklocker.com)

US Patent #: 8,443,640

**Life Simply Inc.**

5200 Clark Ave. #1131

Lakewood, CA 90714-1131

